

RENTAL - SALES - PARTS & SERVICE

Tel: (888) 337-BIGGE or (510) 638-8100 Web: www.bigge.com



Grove Manitowoc National Crane Potain

Grove RT765E-2 Product Guide



Features

- 60 t (65 USt) capacity
- 11 m 33,5 m (36 ft 110 ft) four-section full power boom
- 10,1 m (33 ft) offsettable lattice swingaway extension
- 10,1 m 17,1 m (33 ft 56 ft) bi-fold lattice swingaway extension
- 6,1 m (20 ft) or 12,2 m (40 ft) extension inserts
- 6516 kg (14,365 lb) counterweight pinned to superstructure





Features

MEGAFORM[™] boom

The superstructure features a full-power four-section MEGAFORM[™] boom that can reach to a maximum tip height of 119 ft. The sequence synchronized extension features telescopic boom sections via a single lever joystick controller.



Extensions

An optional bi-fold swingaway lattice extension easily stows on the side of the base boom for easy transport while providing on-board extension from 33 ft - 56 ft for a maximum tip height of 174.5 ft. By adding inserts of 20 ft or 40 ft, the maximum tip height on the RT765E-2 can be extended even further to 194 ft or 214 ft.

An optional 33 ft fixed swingaway is also available with a maximum tip height of 150 ft.





CraneSTAR is an exclusive and innovative crane asset management system that helps improve your profitability and reduce costs by remotely monitoring critical crane data. Visit www.cranestar.com for more information.



Smooth operation

The RT765E-2 has a quick-reeve boom nose and swingaway alignment device to help operators set up smoothly.

Bîgge /



Contents

Specifications	4
Dimensions and weights	7
Working range	8
Load charts	9
Symbols glossary	10





Specifications

Superstructure

Boom

11 m - 33,5 m (36 ft - 110 ft) four-section, full-power sequenced synchronized boom.

Maximum tip height: 36,4 m (119 ft).

*Optional fixed swingaway extension

10,1 m (33 ft) offsettable lattice swingaway extension. Offsettable at 0°, 25° and 45°. Stows alongside base boom section.

Maximum tip height: 45,8 m (150 ft).

*Optional bi-fold swingaway extension

10,1 m - 17,1 m (33 ft - 56 ft) bi-fold lattice swingaway extension. Offsettable at 0°, 25° and 45°. Stows alongside base boom section. Maximum tip height: 53,2 m (174.5 ft).

*Optional 6,1 m (20 ft) or 12,2 m (40 ft) inserts

Installs between boom nose and bi-fold extension, non-stowable. Maximum tip height: 59,1 m (194 ft) with 20 ft insert, 65,2 m (214 ft) with 40 ft insert.

Boom nose

Four nylatron sheaves mounted on heavy-duty tapered roller bearings with removable pin-type rope guards. Quick-reeve type boom nose.

*Optional removable auxiliary boom nose with removable pin type rope guard.

Boom elevation

One double-acting hydraulic cylinder with integral holding valve provides elevation from -3° to 78°.

Load moment and anti-two block system

Standard "Graphic Display" load moment and anti-two block system with audio-visual warning and control lever lockout. These systems provide electronic display of boom angle, length, radius, tip height, relative load moment, maximum permissible load, load indication and warning of impending two-block condition. The standard Work Area Definition System allows the operator to pre-select and define safe working areas. If the crane approaches the pre-set limits, audio-visual warnings aid the operator in avoiding job-site obstructions.



Cab

Full-vision, all-steel fabricated with acoustical lining and tinted safety glass throughout. Deluxe seat incorporates armrest-mounted hydraulic single-axis controllers. Tilt/telescoping steering wheel with various controls incorporated into the steering column. Other standard features include:, hot water heater, cab circulating air fan, sliding side and rear windows, sliding skylight with electric wiper and sunscreen, electric windshield wash/wipe, fire extinguisher, seat belt, air conditioning, and dual cab mounted work light.



Planetary swing with foot-applied multi-disc brake. Spring applied, hydraulically-released swing brake and plunger-type, one position, mechanical house lock operated from cab. *Optional 360° mechanical swing lock. Maximum speed: 2.5 rpm.

Counterweight

6516 kg (14,365 lb) pinned to superstructure.

Hydraulic system

Three main gear pumps with a combined capacity of 465 LPM (123 GPM).

Maximum operating pressure: 27,6 MPa (4000 psi). Two individual post pressure compensated valve banks.

Return line type filter with full flow by-pass protection and service indicator. Replaceable cartridge with micron filtration rating of 5/12/16. 507 L (134 gallon) reservoir. Integral oil cooler. System pressure test ports.

Hoist specifications (GHP30A) main and auxiliary hoist

Main and auxiliary hoist: Model GHP30A

Planetary reduction with automatic spring applied multi-disc brake. Grooved drum. Electronic hoist drum rotation indicator and hoist drum cable followers.

Maximum single line pull: 8363 kg (18,436 lb)

Maximum single line speed: 153 m/min (502 fpm)

Maximum permissible line pull:

7620 kg (16,800 lb) with standard 6 x 37 class rope 7620 kg (16,800 lb) with optional 35 x 7 class rope

4



This information is for reference use only. Operators manual should be consulted and adhered to. Please contact Bigge Crane and Rigging Co. at 888-337-BIGGE or email info@bigge.com for further information.

*Denotes optional equipment



Specifications

Superstructure continued

Rope diameter: 19 mm (3/4 in)

Rope length: 152 m (500 ft) *Optional 152 m (500 ft) 35 x 7 class rope

Rope type: 6 x 37 class EIPS IWRC *Optional 35 x 7 class rotation resistant

Maximum rope stowage: 211 m (695 ft).

Carrier



Chassis

Box section frame fabricated from high-strength, low alloy steel. Integral outrigger housings and front/rear towing, lifting, and tie down lugs.

Outrigger system

Four hydraulic telescoping single-stage double box beam outriggers with inverted jacks and integral holding valves. Three position settings, 100%, 50% and fully retracted. All steel fabricated, quick-release type round outrigger floats, 610 mm (24 in) diameter. Maximum outrigger pad load: 41 731 kg (92,000 lb). Outrigger position monitoring system (required for NA/Canada).



Outrigger controls

Controls and crane level indicator located in cab.



Engine (Tier IV)

Cummins QSB 6.7 L diesel, six cylinders, turbocharged with Cummins Diesel Particulate Exhaust filter/muffler. Meets emissions per U.S.E.P.A. Tier IV and E.U. Stage III B. 179 kW (240 bhp) at 2500 rpm. Maximum torque: 990 N-m (730 ft lb) at 1500 rpm.

Fuel requirement: Maximum of 15 ppm sulphur content (Ultra Low Diesel Fuel).

Note: Tier IV engine Required in North American and European Union countries.



Engine (Tier III)

Cummins QSB 6.7 L diesel, six cylinders, turbocharged, 179 kW (240 bhp) (Gross) at 2500 rpm. Maximum torque: 987 N-m (728 ft lb) at 1500 rpm.

Note: Required for sale outside of North American and European Union countries



Fuel tank capacity

280 L (74 gal)



Spicer powershift with 6 forward and 6 reverse speeds (3 speeds high and 3 speeds low). Front axle disconnect for $4 \ge 2$ travel.



Electrical system

Three 12-volt maintenance free batteries. 12-volt starting and lighting, circuit breakers, battery disconnect switch.

I---I Drive

4 x 4

Steering

Fully independent power steering:

Front: Full hydraulic, steering wheel controlled.

Rear: Full hydraulic, switch controlled.

Provides infinite variations of 4 main steering modes: front only, rear only, crab and coordinated.

Rear steer centered indicating light.

4 wheel outside turning radius - 7,1 m (23 ft 4 in).

Axles

Front: Drive/steer with differential and planetary reduction hubs rigid-mounted to frame.

Rear: Drive/steer with differential and planetary reduction hubs pivot-mounted to frame.

Automatic full hydraulic lockouts on rear axle permit 203 mm (8 in) oscillation only with boom centered over the front.





Specifications

Carrier continued



Full hydraulic split circuit brakes operating on all wheels. Spring-applied, hydraulically released axle-mounted parking brake.

C) Tires

29.5 x 25 - 28PR bias earthmover type.



Full lighting package including turn indicators, head, tail, brake and hazard warning lights.

Maximum speed

37 km/h (23 mph) (no load).

Gradeability (theoretical)

130% (Based on 42 388 kg [93,447 lb] GVW) 29.5 x 25 tires, pumps engaged, 33,6 m (110 ft) boom, bi-fold extension, aux. hoist and cable, and 65 USt hook block.

Miscellaneous standard equipment

Full width steel fenders, full length steel decking, dual rear view mirrors, hook block tiedown, electronic back-up alarm, light package, front stowage well, tachometer, rear wheel position indicator, 36,000 BTU hot water heater, air conditioning package with 28,500 BTU hydraulic driven air conditioning, hoist mirrors, engine distress A/V warning system. Auxiliary hoist control valve arrangement (less hoist). Cold start aid and immersion type engine block heater, 120V 1500 watt. Hoist access platform, CraneSTAR asset management system, Outrigger position monitoring system.

***Optional equipment**

- Auxiliary Hoist Package (includes Model GHP30A) auxiliary hoist with electronic hoist drum rotation indicator, hoist drum cable follower, 152 m (500 ft) of 19 mm (3/4 in) 35 X 7 class wire rope, auxiliary single sheave boom nose.
- Auxiliary Light and Convenience Package: includes superstructure mounted amber flashing light, in-cab LMI light bar, and dual base boom mounted floodlights, rubber mat for stowage trough
- "CE" Mark Conformance (sound abatement foam kits, 3rd wrap indicator, emergency auxiliary steering, dual axis joystick controllers)
- Cross axle differential locks (front and rear)
- 🔰 Manual pump disconnect
- Pintle hook rear
- 360° NYC style positive swinglock
- PAT event recorder
- Hydraulic removable counterweight
- 3rd wrap indicator with function lockout for main hoist or main and auxiliary hoist
- Wireless windspeed indicator
- -29° C (-20° F) cold weather package

BİGGE






Dimensions and weights

Dime	ension	S													
Tire size	A	В	с	D	E	F	G	A	В	с	D	E	F	G	н
29.5 -2 5	14 961 mm (589")	15 368 mm (605")	12 460 mm (491")	11 732 mm (462")	11 342 mm (446")	9004 mm (355")	7662 mm (302")	10 922 m (430")	11 153 mm (439")	7830 mm (308")	7099 mm (280")	6744 mm (266")	4368 mm (172")	3496 mm (138")	2499 mm (98.37")
-	2 Wheel Steer 4 Wheel Steer														

Dimensions for table are represented in milimmeters (inches). exact.





Weights						
	GVW		Front		Re	ar
	kg	lb	kg	lb	kg	Ib
Basic Machine: Including 110 ft main boom, main hoist with 500 ft of wire rope, auxiliary hoist with 500 ft of wire rope, full pinned counterweight, full Decking, A/C, and hoist access platform	40 381	89 024	18 495	40,773	21 887	48,251
ADD: 33 ft -56 ft bi-fold swingaway + extension carrier brackets + aux. boom nose		2788	1997	4402	-732	-1614
Crane Weight	41 646	91,812	20 491	45,175	21 155	46,637
ADD: 60 t (65 USt) 5-sheave hookblock stowed in trough	480	1280	480	1280	0	0
Crane Weight	42 227	93,092	21 072	46,455	21 155	46,637
ADD: 7,5 t (8.3 USt) headache ball tied to O/R cable	161	355	262	578	-101	-223
Crane Weight	42 388	93,447	21 334	47,033	21 053	46,414


Grove RT765E-2



7 Bigge

Working range

110 ft main boom with 33 ft - 56 ft bi-fold swingaway



THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane






This information is for reference use only. Operators manual should be consulted and adhered to. Please contact Bigge Crane and Rigging Co. at 888-337-BIGGE or email info@bigge.com for further information.

🛕 BİGGE

Working range





Grove RT765E-2

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

5⁵⁵⁻² The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane


BİGGE 🧴

This information is for reference use only. Operators manual should be consulted and adhered to. Please contact Bigge Crane and Rigging Co. at 888-337-BIGGE or email info@bigge.com for further information. 9

BİGGE

Working range

110 ft main boom with two inserts and 33 ft - 56 ft bi-fold swingaway



THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane





This information is for reference use only. Operators manual should be consulted and adhered to. Please contact Bigge Crane and Rigging Co. at 888-337-BIGGE or email info@bigge.com for further information. A BİGGE



14,365 lb

<u>[</u>-] 23 ft 4 in

(100%)

Q 360°

Radius					#0001				
in feet				Main bo	om leng	th in fee	t		
leer	36	40	50	^{**} 60	70	80	90	100	110
10	130,000 (69.5)	90,300 (71.5)	90,300 (75.5)	*62,500 (78)					
12	112,500 (65.5)	90,300 (68.5)	90,300 (73)	62,500 (76.5)	*40,200 (78)				
15	93,250 (60)	90,300 (63.5)	90,250 (69.5)	62,500 (73.5)	40,200 (76)	*40,200 (78)			
20	71,550 (49.5)	71,500 (55)	71,300 (63)	62,500 (68)	40,200 (71.5)	40,200 (74.5)	40,200 (78)	*36,900 (78)	
25	56,650 (36.5)	56,600 (45)	56,350 (56)	53,650 (63)	40,200 (67)	40,200 (70.5)	37,950 (73)	34,900 (75)	*25,150 (78)
30	43,500 (11.5)	44,300 (32)	43,950 (48.5)	43,650 (57.5)	40,200 (62.5)	36,050 (66.5)	32,750 (69.5)	30,200 (72)	25,150 (74)
35			33,550 (40)	33,700 (51.5)	34,700 (58)	31,450 (62.5)	28,550 (66)	26,400 (69)	24,700 (71.5)
40			25,800 (28)	26,150 (44.5)	26,900 (52.5)	27,700 (58.5)	25,200 (62.5)	23,300 (66)	21,800 (68.5)
45				20,650 (36.5)	21,450 (47)	22,300 (54)	22,400 (59)	20,700 (62.5)	19,400 (65.5)
50				16,550 (26.5)	17,400 (41)	18,250 (49.5)	19,100 (55)	18,550 (59.5)	17,350 (62.5)
55					14,300 (33.5)	15,150 (44)	16,000 (51)	16,400 (56)	15,600 (60)
60					11,800 (23.5)	12,700 (38.5)	13,550 (46.5)	13,950 (52.5)	14,100 (56.5)
65						10,700 (31.5)	11,550 (41.5)	11,950 (48.5)	12,300 (53.5)
70						9010 (22.5)	9920 (36)	10,250 (44)	10,650 (50)
75							8510 (29.5)	8890 (39.5)	9250 (46)
80							7260 (21)	7690 (34.5)	8050 (42.5)
85								6620 (28.5)	7010 (38)
90								5630 (20)	6100 (33)
95									5240 (27)
100									4480 (19.5)
Minimum	n boom ar	ngle (°) foi	rindicate	d length (no load)		L		0
	n boom le								110

NOTE: () Boom angles are in degrees.

#LMI operating code. Refer to LMI manual for operating instructions. *This capacity is based on maximum boom angle.

	Lifting capacities at zero degree boom angle								
Boom		Main boom length in feet							
angle	36	36 40 50 [∞] 60 70 80 90 100 110							
0°	0° 30,350 25,700 17,950 13,050 10,050 7790 6300 4900 3900 (30.1) (34.2) (44.2) (54.6) (64.2) (74.2) (84.2) (94.2) (104.2)								
NOTE:()F	NOTE: () Reference radii in feet. 80039604								

** Boom length is with inner-mid fully extended and outer-mid & fly fully retracted.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

Grove RT765E-2 The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane

BİGGE

This information is for reference use only. Operators manual should be consulted and adhered to. Please contact Bigge Crane and Rigging Co. at 888-337-BIGGE or email info@bigge.com for further information.

BİGGE



36 ft - 110 ft 33 ft - 56 ft

14,365 lb

23 ft 4 in (100%)

360°

--

		33 ft LENGTI	1		56 ft LENGTI	ł
Radius in	0° OFFSET	25° OFFSET	45° OFFSET	0° OFFSET	25° OFFSET	45° OFFSET
feet	#0021	#0022	#0023	#0041	#0042	#0043
30	12,900 (78)					
35	12,900 (76.5)			*8330 (78)		
40	12,900 (74.5)	*10,850 (78)		8330 (77.5)		
45	12,900 (72)	10,450 (76.5)	*7410 (78)	8330 (76)		
50	12,100 (70)	10,000 (74.5)	7200 (77.5)	8330 (74)		
55	11,100 (68)	9220 (72.5)	6990 (75.5)	8250 (72)	*5300 (78)	
60	10,100 (65.5)	8550 (70)	6800 (73)	7540 (70.5)	5140 (77.5)	
65	9130 (63.5)	7930 (67.5)	6650 (70.5)	7160 (68.5)	5100 (75.5)	*3860 (78)
70	8460 (61)	7380 (65.5)	6490 (68)	6820 (66.5)	5100 (73.5)	3790 (77.5)
75	7840 (58.5)	6900 (63)	6370 (65.5)	6300 (64.5)	4800 (71.5)	3660 (75.5)
80	7230 (56)	6470 (60.5)	6110 (63)	5810 (62.5)	4580 (69.5)	3550 (73)
85	6690 (53.5)	6070 (58)	5780 (60)	5370 (60.5)	4470 (67)	3,450 (71)
90	6,140 (51)	5720 (55.5)	5480 (57.5)	4980 (58.5)	4330 (65)	3410 (68.5)
95	5670 (48.5)	5400 (52.5)	5200 (54.5)	4,630 (56.5)	4070 (63)	3,300 (66.5)
100	5150 (45.5)	5100 (49.5)	4950 (51.5)	4320 (54)	3830 (60.5)	3260 (64)
105	4650 (42.5)	4760 (46.5)	4650 (48)	4040 (52)	3620 (58.5)	3220 (61.5)
110	4,070 (39.5)	(40.3) 4430 (43)	(40)	3770 (49.5)	3410 (56)	3180 (59)
115	3540 (36)	3930 (39.5)		3540 (47.5)	3230 (53.5)	3060 (56)
120	3060 (32)	3400 (35)		3310 (45)	3050 (50.5)	2940 (53)
125	2630 (27)	2920 (30)		3070 (42)	2890 (48)	2800 (50)
130	2230 (21.5)	(30)		2770 (39.5)	2730	(50)
135	(21.3)			(39.5) 2400 (36.5)	(45) 2590 (41.5)	
140				2050	2410	
145				(33) 1720 (20)	(38) 2040 (33.5)	
150				(29) 1420 (24.5)	(3.5)	
Minimum boom angle (°) for indicated length (no load)	19	29	47	23	32	49
Maximum boom length (ft) at 0° boom angle (no load)		100			90	

NOTES:

1. All capacities above the bold line are based on structural strength of boom extension.

2. 33 ft and 56 ft boom extension lengths may be used for single line lifting service.

3. For main boom lengths less than 110 ft with the boom extension erected, the rated loads are determined by boom angle. Use only the column which corresponds to the boom extension length and offset for which the machine is set up. For boom angles not shown, use the rating of the next lower boom angle.

4. WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.

5. Boom angle is the angle above or below horizontal of the longitudinal axis of the boom base section after lifting rated load.

6. Capacities listed are with outriggers fully extended and vertical jacks set only.

7. When lifting over the main boom nose with 33 ft or 56 ft extension erected, the outriggers must be fully extended or 50% extended (17 ft spread).

#LMI operating code. Refer to LMI manual for operating instructions. *This capacity is based upon maximum boom angle.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane







14,365 lb

Load chart

1. All capacities above the bold line are based on structural

3. For main boom lengths less than 110 ft with the boom extension erected, the rated loads are determined by boom angle. Use only the column which corresponds to the boom extension length and offset for which the machine is set up. For boom angles not shown, use rating of the next lower

4. WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without

5. Boom angle is the angle above or below horizontal of the longitudinal axis of the boom base section after lifting rated

6. Capacities listed are with outriggers fully extended and

7. When lifting over the main boom nose with 56 ft extension erected and 20 ft insert, the outriggers must be fully

2. The 56 ft boom extension length may be used for single line

-Mil	
36 ft - 110 ft	56 ft

000 20 ft

ŀ−. 23 ft 4 in (100%)

Q

360°

NOTES:

strength of boom extension.

lifting service only.

boom angle.

advance warning.

vertical jacks set only.

extended or 50% extended (17 ft spread).

load.

		56 ft LENGTH	1
Radius in	0°	25°	45°
feet	OFFSET #0084	OFFSET #0085	OFFSET #0086
	*6300	#0005	#0000
40	(78)		
45	6300 (77.5)		
50	6000		
50	(76.5)		
55	5990 (75)		
	5980	*4840	
60	(73)	(78)	
65	5510	4840 (77 F)	
	(71.5) 5010	(77.5) 4440	
70	(70)	(76)	
75	4560	4050 (74 E)	*3760
	(68) 4170	(74.5) 3870	(78) 3460
80	(66.5)	(72.5)	(76.5)
85	3820	3570	3260
	(64.5) 3520	(71) 3320	(74.5) 2960
90	(63)	(69)	(72.5)
95	3220	3070	2770
	(61) 2980	(67) 2880	(70.5) 2570
100	(59)	(65.5)	(68.5)
105	2780	2680	2460
100	(57.5) 2530	(63.5) 2480	(66.5) 2340
110	(55.5)	(61.5)	(64.5)
115	2340	2280	2200
	(53.5) 2190	(59.5) 2140	(62) 2050
120	(51.5)	(57.5)	(60)
125	2000	1990	1910
-25	(49.5) 1850	(55) 1850	(57.5) 1810
130	(47.5)	(53)	(55)
135	1720	1750	1670
.55	(45)	(50.5)	(52.5)
140	1610 (43)	1610 (48)	
145		1520	
<u>ر</u> ي.		(45)	
150		1370 (42.5)	
Minimum boom angle	42		F.6
(°) for indicated length (no load)	42	41	50
Maximum boom length			•
(ft) at 0° boom angle (no load)		70	
			80039609A

NOTE: () Boom angles are in degrees. #LMI operating code. Refer to LMI manual for operating

instructions.

*This capacity is based upon maximum boom angle.

Grove RT765E-2

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane

13





10 ft 56 ft	🕑 40 ft		3 ft 4 in (100%)				
De diss	56 ft LENGTH						
Radius in	#0084	#0085	#0086				
feet	0° OFFSET	25° OFFSET	45° OFFSET				
50	4510	OFFSET	OFFSET				
50	(78)						
55	4210 (77)						
60	3910						
00	(75.5)						
65	3710 (74)						
70	3410	*3710					
	(72.5) 3220	(78) 3420					
75	(71)	(76.5)					
80	2820 (69.5)	3120 (75)					
05	2520	2820	2730				
85	(68)	(73.5)	(77.5)				
90	2320 (66.5)	2620 (72)	2530 (75.5)				
95	2030	2330	2340				
	(65) 1830	(70.5) 2130	(74) 2140				
100	(63)	(68.5)	(72)				
105	1630	1930	1940				
	(61.5) 1440	(67) 1730	(70.5) 1740				
110	(60)	(65.5)	(68.5)				
115	1240 (58.5)	1540 (63.5)	1550 (66.5)				
120	1140	1340	1450				
120	(56.5)	(62)	(64.5)				
125		1240 (60)	1260 (62.5)				
130		1050	1160				
.50	NoloadCt	(58)	(60.5)				
Min. boom	NU LUAU SL	ability Data	1				
angle (°) for indicated length	55	57	59				
Max. boom length (ft) at 0° boom angle		40					

#LMI operating code. Refer to LMI manual for

instructions.

NOTES:

1. All capacities above the bold line are based on structural strength of boom extension.

2. The 56 ft boom extension length may be used for single line lifting service only.

3. For main boom lengths less than 110 ft with the boom extension erected, the rated loads are determined by boom angle. Use only the column which corresponds to the boom extension length and offset for which the machine is set up. For boom angles not shown, use rating of the next lower boom angle.

4. **WARNING:** Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.

5. Boom angle is the angle above or below horizontal of the longitudinal axis of the boom base section after lifting rated load.

6. Capacities listed are with outriggers fully extended and vertical jacks set only.

7. When lifting over the main boom nose with 56 ft extension erected and 40 ft insert, the outriggers must be fully extended or 50% extended (17 ft spread).

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane

14

BİGGE







Radius			#9005						
in		Main boom length in feet							
feet	36	40	50	*60	70				
10	45,300 (69.5)	39,700 (71.5)							
12	41,500 (66)	39,700 (68.5)	29,600 (73)						
15	32,450 (60)	31,750 (63.5)	26,450 (69.5)	20,900 (73.5)					
20	19,200 (50)	18,850 (55)	18,750 (63)	18,550 (68)	17,300 (71.5)				
25	12,600 (36.5)	12,350 (44.5)	12,250 (56)	12,050 (63)	12,550 (67)				
30	8650 (11.5)	8530 (31.5)	8250 (48.5)	8150 (57)	8710 (62.5)				
35			5600 (39.5)	5450 (51)	6170 (57.5)				
40			3700 (28)	3410 (44)	4300 (52)				
45				1760 (36)	2850 (46.5)				
50					1250 (40)				
Minimum b (no load)	oom angle	35	39						
Maximum l (no load)	oom lengtl	5	0						

NOTE: () Reference boom angles in degrees.

Lifting capacities at zero degree boom angle								
Boom Main boom length in feet								
angle	36	36 40 50						
0° 8580 6310 2270 (30.1) (34.2) (44.2)								
Note: () Reference radii in feet. 80039611								

Note: () Reference radii in feet

#LMI operating code. Refer to LMI manual for instructions. *60 ft. boom length is with inner-mid extended and outer-mid & fly retracted.

NOTES TO ALL RUBBER CAPACITY CHARTS:

1. Capacities are in pounds and do not exceed 75% of tipping loads as determined by test in accordance with SAE J765.

2. Capacities are applicable to machines equipped with 29.5 x 25 (28 or 34 ply General/Titan, Denman Rock Plus, Denman Broadway and Advance bias plus ply) tires at 65 psi cold inflation pressure.

3. Capacities appearing above the bold line are based on structural strength and tipping should not be relied upon as a capacity limitation.

4. Capacities are applicable only with machine on firm level surface.

5. On rubber lifting with boom extensions not permitted.

6. For pick and carry operation, boom must be centered over front of machine, mechanical swing lock engaged and load restrained from swinging.

7. Axle lockouts must be functioning when lifting on rubber.

8. All lifting depends on proper tire inflation, capacity and condition. Capacities must be reduced for lower tire inflation pressures. See lifting capacity chart for tire used. Damaged tires are hazardous to safe operation of crane.

9. Creep - not over 200 ft of movement in any 30 minute period and not exceeding 1 mph.

Grove RT765E-2





	=N)	J	
36	ft - '	110	ft

Boom angle

0°

14,365 lb

Q Pick and carry Over up to 2.5 mph front 29.5 x 25 tires

C

-Mil 36 ft - 110 ft

14.365 lb

Creep speed Over front

Q

C

Radius	#9006						
in	Main boom length in feet						
feet	36	40	50	*60	70		
10	47,200 (69.5)	44,000 (71.5)	34,000 (75.5)				
12	43,450 (66)	42,500 (68.5)	34,000 (73)	28,500 (76.5)			
15	35,900 (60)	35,200 (63.5)	34,000 (69.5)	28,500 (73.5)	21,350 (75.5)		
20	27,000 (50)	26,650 (55)	26,300 (63)	26,500 (68)	21,350 (71.5)		
25	20,750 (36.5)	20,550 (44.5)	20,500 (56)	20,550 (63)	21,300 (67)		
30	16,150 (11.5)	16,100 (31.5)	16,200 (48.5)	16,200 (57)	17,000 (62.5)		
35			12,850 (39.5)	12,850 (51)	13,750 (57.5)		
40			9550 (28)	9970 (44)	10,950 (52)		
45				7470 (36)	8470 (46.5)		
50				5550 (26)	6540 (40)		
55					5010 (33)		
60					3760 (23)		
Minimum t	Minimum boom angle (°) for indicated length (no load)						
Maximum I	Maximum boom length (ft) at 0° boom angle (no load)						
NOTE: () Reference boom angles in degrees.							

Radius	#9030				
in	Main boom length in feet				
feet	36	40	50	*60	70
10	47,200 (69.5)	44,000 (71.5)	34,000 (75.5)		
12	47,200 (66)	44,000 (68.5)	34,000 (73)	28,500 (76.5)	
15	43,250 (60)	42,500 (63.5)	34,000 (69.5)	28,500 (73.5)	21,350 (75.5)
20	32,950 (50)	32,600 (55)	32,250 (63)	28,500 (68)	21,350 (71.5)
25	25,450 (36.5)	24,850 (44.5)	25,250 (56)	25,250 (63)	21,350 (67)
30	17,850 (11.5)	17,250 (31.5)	17,800 (48.5)	18,050 (57)	19,000 (62.5)
35			12,950 (39.5)	13,300 (51)	14,300 (57.5)
40			9550 (28)	9970 (44)	10,950 (52)
45				7470 (36)	8470 (46.5)
50				5550 (26)	6540 (40)
55					5010 (33)
60					3760 (23)
Minimum boom angle (°) for indicated length (no load) (0
Maximum boom length (ft) at 0° boom angle (no load) 70					70
NOTE: () Reference boom angles in degrees.					

		I	Lifting capacities at zero degree boom angle				
Boom			Main boom length in feet				
70		angle	36	40	50	*60	
2,880		00	17,750	12,950	7,390	4,140	

(34.2)Note: () Reference radii in feet

40

12,950

#LMI operating code. Refer to LMI manual for instructions. *60 ft. boom length is with inner-mid extended and outer-mid & fly retracted.

Lifting capacities at zero degree boom angle

Main boom length in feet

50

7,390

(44.2)

°60

4,140

(54.6)

NOTES TO ALL RUBBER CAPACITY CHARTS:

36

16,100

(30.1)

1. Capacities are in pounds and do not exceed 75% of tipping loads as determined by test in accordance with SAE J765.

2. Capacities are applicable to machines equipped with 29.5 x 25 (28 or 34 ply General/Titan, Denman Rock Plus, Denman Broadway and Advance bias plus ply) tires at 65 psi cold inflation pressure

3. Capacities appearing above the bold line are based on structural strength and tipping should not be relied upon as a capacity limitation

4. Capacities are applicable only with machine on firm level surface.

*60 ft. boom length is with inner-mid extended and outer-mid & fly retracted.

(30.1)

Note: () Reference radii in feet.

0

5. On rubber lifting with boom extensions not permitted.

(34.2)

#LMI operating code. Refer to LMI manual for instructions.

(44.2)

(54.6)

6. For pick and carry operation, boom must be centered over front of machine, mechanical swing lock engaged and load restrained from swinging.

7. Axle lockouts must be functioning when lifting on rubber.

8. All lifting depends on proper tire inflation, capacity and condition. Capacities must be reduced for lower tire inflation pressures. See lifting capacity chart for tire used. Damaged tires are hazardous to safe operation of crane.

9. Creep - not over 200 ft of movement in any 30 minute period and not exceeding 1 mph.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane



BİGGE



70

2,880

(64.2)

80039612

(64.2)

Load handling

Weight reductions for load handling devices			
33 ft - 56 ft : Folding boo	m extension: Without block or ball	With 355 lb overhaul ball	
*33 ft extension (erected)	3850 lb	5980 lb	
*56 ft extension (erected)	8620 lb	12,170 lb	
Folding extension with 2	0 ft insert:		
*33 ft extension (erected)	7480 lb	10,370 lb	
*56 ft extension (erected)	13,320 lb	17,740 lb	
Folding extension with 40 ft insert:			
*33 ft extension (erected)	9990 lb	12,360 lb	
*56 ft extension (erected)	14,610 lb	17,730 lb	
[°] Reduction of main boom capacities (no deduct required for stowed boom extension).			
Auxiliary boom nose:			
	130 lb		
Hookblocks and headache balls:			
65 USt, 5-sheave	1280 lb +		
8.3 USt, overhaul ball 355 lb +			
+Refer to rating plate for actual weight			

+Refer to rating plate for actual weight

When lifting over swingaway and/or jib combinations, deduct total weight of all load handling devices reeved over main boom nose directly from swingaway or jib capacity.


NOTE: All load handling devices and boom attachments are considered part of the load and suitable allowances MUST BE MADE for their combined weights. Weights are for Grove furnished equipment.

Line pulls and reeving information				
Hoists	Cable specs	Permissable line pulls	Nominal cable length	
Main	19 mm (3/4 in) 6 x 37 class, EIPS, IWRC Special Flexible Min. breaking strength 58,800 lb	16,800 lb	500 ft	
Main and auxiliary	19 mm (3/4 in) 35x7 Class Rotation Resistant (non- rotating) Min. breaking strength 85,800 lb	16,800 lb	500 ft	

The approximate weight of 3/4 in wire rope is 1.5 lb/ft.

Hoist performance				
Wire rope layer	Hoist line pulls two-speed hoist		Drum rope capacity (ft)	
	Low available Ib°	High available Ib*	Layer	Total
1	18,134	9067	101	101
2	16,668	8334	110	211
3	15,420	7710	120	331
4	14,347	7174	129	460
5	13,413	6707	139	599
6	12,594	6297	149	748
*Max lift	*Max lifting capacity: 6x37 and 35x7 class = 16,800 lb			

Tire inflation - PSI (BAR)				
Size (Front and Rear)	TRA Code	Lifting service, general travel and extended travel		
29.5 x 25 (28 or 34) General/Titan, Denman Broadway/Rock Plus	E-3	65 (4.5) See operator's manual for extended roading.)		



Bold lines determine the limiting position of any laod for operation withing working areas indicated.

Grove RT765E-2

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

65E-2 The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane

17







18

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE.

The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane



This information is for reference use only. Operators manual should be consulted and adhered to. Please contact Bigge Crane and Rigging Co. at 888-337-BIGGE or email info@bigge.com for further information.

🛕 BİGGE





19

Grove RT765E-2

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane

BİGGE



Manitowoc National Crane Potain Grove



Manitowoc Cranes

Regional headquarters

Americas

Manitowoc, Wisconsin, USA Tel: +1 920 684 6621 Fax: +1 920 683 6277

Shady Grove, Pennsylvania, USA Tel: +1717 597 8121 Fax: +1717 597 4062

Europe, Middle East, Africa Ecully, France Tel: +33 (0)4 72 18 20 20 Fax: +33 (0)4 72 18 20 00

China Shanghai, China Tel: +86 21 6457 0066 Fax: +86 21 6457 4955

Greater Asia-Pacific Singapore Tel: +65 6264 1188 Fax: +65 6862 4040

Regional offices

Americas

Brazil Alphaville Mexico Monterrey Chile Santiago

Europe, Middle East, Africa

Czech Republic Netvorice France Baudemont Cergy Decines Germany Langenfeld Hungary **Budapest** Italy Lainate Netherlands Breda Poland Warsaw Portugal Baltar Russia Moscow U.A.E. Dubai U.K. Buckingham

China Beijing Chengdu Guangzhou Xian

Greater Asia-Pacific

Australia Adelaide Brisbane Melbourne Sydney India Calcutta Chennai Delhi Hyderabad Pune Korea Seoul Philippines Makati City Singapore

TaiAn Zhangjiagang

China

Factories Brazil Alphaville

This document is non-contractual. Constant improvement and engineering progress make it necessary that we reserve the right to make specification, equipment, and price changes without notice. Illustrations shown may include optional equipment and accessories and may not include all standard equipment.

France Charlieu Moulins Germany Wilhelmshaven India Pune Italy Niella Tanaro Portugal Baltar Fânzeres Slovakia Saris USA Manitowoc Port Washington Shady Grove

©2011 Manitowoc Form No.RT765E-2 PG Part No.10-009-2M-0911

www.manitowoc.com



